

**SECTION 22 42 13.16**  
**COMMERCIAL URINALS**

**PART 1 - GENERAL**

**1.1 SUMMARY**

**A. Section Includes:**

1. Wall-hung urinals.
2. Urinal flushometer valves.
3. Supports.

**1.2 ACTION SUBMITTALS**

**A. Product Data:** For each type of product.

1. Include construction details, material descriptions, dimensions of individual components and profiles, and finishes for urinals.
2. Include rated capacities, operating characteristics, electrical characteristics, and furnished specialties and accessories.

**PART 2 - PRODUCTS**

**2.1 WALL-HUNG URINALS**

**A. Urinals - Wall Hung, Back Outlet, Washdown: Accessible .**

1. Fixture:
  - a. Standards: ASME A112.19.2/CSA B45.1 and ASME A112.19.5/CSA B45.15.
  - b. Material: Vitreous china.
  - c. Type: Washdown with extended shields.
  - d. Strainer or Trapway: Manufacturer's standard strainer with integral trap.
  - e. Water Consumption: 0.125 gpf .
  - f. Spud Size and Location: NPS 3/4, top.
  - g. Outlet Size and Location: NPS 2, back.
  - h. Color: White .
2. Waste Fitting:
  - a. Standard: ASME A112.18.2/CSA B125.2 for coupling.
  - b. Size: NPS 2.
3. Support: Type I urinal carrier with fixture support plates and coupling with seal and fixture bolts and hardware matching fixture. Include rectangular, steel uprights.
4. Urinal Mounting Height: Standard Handicapped/elderly according to ICC A117.1.

## 2.2 URINAL FLUSHOMETER VALVES

### A. Lever-Handle, Diaphragm Flushometer Valves: .

1. Standard: ASSE 1037/ASME 112.1037/CSA B125.37.
2. Minimum Pressure Rating: 125 psig.
3. Features: Include integral check stop and backflow-prevention device.
4. Material: Brass body with corrosion-resistant components.
5. Exposed Flushometer-Valve Finish: Chrome plated.
6. Style: Exposed .
7. Consumption: 0.125 gal. per flush.
8. Minimum Inlet: NPS 3/4 .
9. Minimum Outlet: NPS 3/4 .

## 2.3 SUPPORTS

### A. Type I Urinal Carrier:

1. Standard: ASME A112.6.1M.

### B. Type II Urinal Carrier:

1. Standard: ASME A112.6.1M.

## PART 3 - EXECUTION

### 3.1 EXAMINATION

- A. Examine roughing-in of water supply and sanitary drainage and vent piping systems to verify actual locations of piping connections before urinal installation.
- B. Examine walls and floors for suitable conditions where urinals will be installed.
- C. Proceed with installation only after unsatisfactory conditions have been corrected.

### 3.2 INSTALLATION

#### A. Urinal Installation:

1. Install urinals level and plumb according to rough-in drawings.
2. Install wall-hung, back-outlet urinals onto waste fitting seals and attached to supports.
3. Install accessible, wall-mounted urinals at mounting height for the handicapped/elderly, according to ICC A117.1.

#### B. Support Installation:

1. Install supports, affixed to building substrate, for wall-hung urinals.

2. Use off-floor carriers with waste fitting and seal for back-outlet urinals.
3. Use chair-type carrier supports with rectangular steel uprights for accessible urinals.

C. Flushometer-Valve Installation:

1. Install flushometer-valve water-supply fitting on each supply to each urinal.
2. Attach supply piping to supports or substrate within pipe spaces behind fixtures.
3. Install lever-handle flushometer valves for accessible urinals with handle mounted on open side of compartment.

D. Wall Flange and Escutcheon Installation:

1. Install wall flanges or escutcheons at piping wall penetrations in exposed, finished locations.
2. Comply with escutcheon requirements specified in Section 22 05 00 "Common Work Results for Plumbing."

E. Joint Sealing:

1. Seal joints between urinals and walls and floors using sanitary-type, one-part, mildew-resistant silicone sealant.
2. Match sealant color to urinal color.

### 3.3 PIPING CONNECTIONS

- A. Connect urinals with water supplies and soil, waste, and vent piping. Use size fittings required to match urinals.
- B. Comply with water piping requirements specified in Section 22 11 16 "Domestic Water Piping."
- C. Comply with soil and waste piping requirements specified in Section 22 13 16 "Sanitary Waste and Vent Piping."
- D. Where installing piping adjacent to urinals, allow space for service and maintenance.

### 3.4 ADJUSTING

- A. Operate and adjust urinals and controls. Replace damaged and malfunctioning urinals, fittings, and controls.
- B. Adjust water pressure at flushometer valves to produce proper flow.

END OF SECTION 22 42 13.16

This page intentionally left blank.