

## SECTION 23 34 23 - HVAC POWER VENTILATORS

### PART 1 - GENERAL

#### 1.1 RELATED DOCUMENTS

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

#### 1.2 SUMMARY

- A. Section Includes:
  - 1. Ceiling-mounted ventilators.

#### 1.3 ACTION SUBMITTALS

- A. Product Data: For each type of product.
  - 1. Construction details, material descriptions, dimensions of individual components and profiles, and finishes for fans.
  - 2. Rated capacities, operating characteristics, and furnished specialties and accessories.
  - 3. Certified fan performance curves with system operating conditions indicated.
  - 4. Certified fan sound-power ratings.
  - 5. Motor ratings and electrical characteristics, plus motor and electrical accessories.
  - 6. Material thickness and finishes, including color charts.
  - 7. Dampers, including housings, linkages, and operators.
  - 8. Prefabricated roof curbs.
  - 9. Fan speed controllers.

#### 1.4 INFORMATIONAL SUBMITTALS

#### 1.5 CLOSEOUT SUBMITTALS

- A. Operation and Maintenance Data: For HVAC power ventilators to include in normal and emergency operation, and maintenance manuals.

### PART 2 - PRODUCTS

#### 2.1 PERFORMANCE REQUIREMENTS

- A. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, by an NRTL, and marked for intended location and application.

- B. NFPA Compliance: Comply with NFPA 90A for design, fabrication, and installation of unit components.
- C. ASHRAE 62.1 Compliance: Applicable requirements in ASHRAE 62.1, Section 5 - "Systems and Equipment" and Section 7 - "Construction and Startup."
- D. ASHRAE/IES 90.1 Compliance: Applicable requirements in ASHRAE/IES 90.1, Section 6 - "Heating, Ventilating, and Air-Conditioning."

## 2.2 CEILING-MOUNTED VENTILATORS

- A. Housing: Galvanized steel.
- B. Fan Wheel: Centrifugal wheels directly mounted on motor shaft. Fan shrouds, motor, and fan wheel removable for service.
- C. Back-draft damper: Integral.
- D. Grille: Galvanized steel, louvered grille with flange on intake and thumbscrew or spring retainer attachment to fan housing.
- E. Electrical Requirements: Junction box for electrical connection on housing and receptacle for motor plug-in.
- F. Accessories:
  - 1. Manual Starter Switch: Single-pole rocker switch assembly with cover and pilot light.
  - 2. Motion Sensor: Motion detector with adjustable shutoff timer.
  - 3. Manufacturer's standard roof jack or wall cap, and transition fittings.

## 2.3 MOTORS

- A. Comply with NEMA designation, temperature rating, service factor, and efficiency requirements for motors specified in Section 23 05 13 "Common Motor Requirements for HVAC Equipment."
  - 1. Motor Sizes: Minimum size as indicated. If not indicated, large enough so driven load will not require motor to operate in service factor range above 1.0.

## 2.4 SOURCE QUALITY CONTROL

- A. AMCA Certification for Fan Sound Performance Rating: Test, rate, and label in accordance with AMCA 311.
- B. AMCA Certification for Fan Aerodynamic Performance Ratings: Test, rate, and label in accordance with AMCA 211.
- C. AMCA Certification for Fan Energy Index (FEI): Test, rate, and label in accordance with AMCA 211.

- D. UL Standards: Power ventilators shall comply with UL 705. Power ventilators for use for restaurant kitchen exhaust shall also comply with UL 762.

### PART 3 - EXECUTION

#### 3.1 INSTALLATION, GENERAL

- A. Install power ventilators level and plumb.
- B. Equipment Mounting:
  - 1. Ceiling Units: Suspend units from structure; use steel wire or metal straps.
- C. Install units with clearances for service and maintenance.
- D. Label units according to requirements specified in Section 23 05 53 "Identification for HVAC Piping and Equipment."

#### 3.2 DUCTWORK CONNECTIONS

- A. Drawings indicate general arrangement of ducts and duct accessories. Make final duct connections with flexible connectors. Flexible connectors are specified in Section 23 33 00 "Air Duct Accessories."

#### 3.3 ELECTRICAL CONNECTIONS

- A. Connect wiring according to Section 26 05 19 "Low-Voltage Electrical Power Conductors and Cables."
- B. Ground equipment according to Section 26 05 26 "Grounding and Bonding for Electrical Systems."
- C. Install electrical devices furnished by manufacturer, but not factory mounted, according to NFPA 70 and NECA 1.
  - 1. Nameplate shall be laminated acrylic or melamine plastic signs, as specified in Section 26 05 53 "Identification for Electrical Systems."
  - 2. Nameplate shall be laminated acrylic or melamine plastic signs with a black background and engraved white letters at least 1/2 inch high.

#### 3.4 CONTROL CONNECTIONS

- A. Install control and electrical power wiring to field-mounted control devices.
- B. Connect control wiring according to Section 26 05 23 "Control-Voltage Electrical Power Cables."

### 3.5 STARTUP SERVICE:

#### A. Perform startup service.

1. Complete installation and startup checks in accordance with manufacturer's written instructions.
2. Verify that shipping, blocking, and bracing are removed.
3. Verify that unit is secure on mountings and supporting devices and that connections to ducts and electrical components are complete. Verify that proper thermal-overload protection is installed in motors, starters, and disconnect switches.
4. Verify that cleaning and adjusting are complete.
5. For direct-drive fans, verify proper motor rotation direction and verify fan wheel free rotation and smooth bearing operation.
6. For belt-drive fans, disconnect fan drive from motor, verify proper motor rotation direction, and verify fan wheel free rotation and smooth bearing operation. Reconnect fan drive system, align and adjust belts, and install belt guards.
7. Adjust belt tension.
8. Adjust damper linkages for proper damper operation.
9. Verify lubrication for bearings and other moving parts.
10. Verify that manual and automatic volume control and fire and smoke dampers in connected ductwork systems are in fully open position.
11. Disable automatic temperature-control operators, energize motor and confirm proper motor rotation and unit operation, adjust fan to indicated rpm, and measure and record motor voltage and amperage.
12. Shut unit down and reconnect automatic temperature-control operators.
13. Remove and replace malfunctioning units and retest as specified above.

### 3.6 ADJUSTING

- A. Adjust damper linkages for proper damper operation.
- B. Adjust belt tension.
- C. Lubricate bearings.
- D. Comply with requirements in Section 23 05 93 "Testing, Adjusting, and Balancing for HVAC."

### 3.7 CLEANING

- A. After completing system installation and testing, adjusting, and balancing and after completing startup service, clean fans internally to remove foreign material and construction dirt and dust.

END OF SECTION 23 34 23